



TRACTOR

PARTS CATALOG

TEILE KATALOG

CATALOGUE DE PIECES

CATALOGO DE PIEZAS

OWNERS EDITION

AUSGABE FÜR EIGENTÜMER

EDITION DU PROPRIÉTAIRE

EDICION DEL PROPIETARIO

1965/—

SUPER MAJOR

INSTRUCTIONS FOR ORDERING

1. Refer to Index for figure number and page number of illustration part required is located on.
2. Select part required from illustration and obtain item number of this part.
3. Quote figure number, item number and Tractor model and serial number information shown on the inside front cover.
4. With the above information your authorized Ford Tractor Dealer can identify the number and proper part required.

INDEX

Figure No.	Description	Page
WHEELS		
1A1	Front Wheels.....	1
1B1	Standard Rear Wheels.....	2
1B3	Power Adjustable Rear Wheels.....	3
WEIGHTS		
1C1	Front End Weights.....	4
1C2	Front Wheel Weights.....	5
1C5	Rear Wheel Weights 36" and 38".....	6
BRAKES		
2A3	* Brakes and Brake Controls.....	7
2B1	Handbrake.....	8
FRONT AXLE AND STEERING		
3A5	Front Axle and Steering—Manual.....	9
3A6	Front Axle and Steering—Power.....	10
3B4	Steering Gear Assembly.....	11
3C1	Pump and Reservoir Assembly.....	12
3D3	Cylinder Assembly—Power Steering.....	13
REAR AXLE		
4A3	Rear Axle and Differential.....	14
4B3	Differential Lock Linkage.....	15
4C3	Center Housing.....	16

INDEX

Figure No.	Description	Page
HYDRAULIC CONTROLS		
5A2	Hydraulic Lift Cover	17
5B3	Hydraulic Lift Shaft	18
5B4	Hydraulic Lift Cylinder	19
5D4	Hydraulic Lift Linkage	20
5D4A	Flexible Lower Lift Links	21
5D7	Stabilizer Kits	22
5E3	Swinging Drawbar and Hanger	23
5F1	Drawbar Stay Kits	24
5G1	Selector Valve Assembly	25
5G2	Single Spool Valve Assembly	26
5G3	Deluxe Single and Double Spool Valve	27
5H3	Pipe and Coupling Kits	28
ENGINE—DIESEL		
6A3	Cylinder Head and Block	29
6B3	Crankshaft and Flywheels	30
6C3	Camshaft and Rocker Arms	31
6D2	Pistons and Connecting Rods	32
6E2	Oil Pump (Sump) Assembly	33
6F2	Oil Filter Assembly	34
6G3	Manifold and Muffler	35
TRANSMISSION, CLUTCH AND P.T.O.		
7C2 & 5	7 and 8 Speed Transmission	36, 7
7D5	Independent P.T.O. Assembly	38
7D6	P.T.O. Guard Assembly	39
7E3	Clutch Controls	40
7E6	Single Clutch Assembly	41
7F2 to 7Q2	Select-O-Speed Transmission	42 to 51


INDEX


Figure No.	Description	Page
COOLING SYSTEM		
8A2	Radiator.....	52
8B1	Water Pump.....	53
FUEL SYSTEM—DIESEL		
9A3	Fuel System.....	54
9B2	Air Cleaner.....	55
9C3	Throttle Control.....	56
9E2	Fuel Injection Pump.....	57
9F2	Fuel Pump Assembly.....	58
9G1	Fuel Primer Kit.....	59
9G2	Cold Start Installation.....	60
HYDRAULIC PUMP		
10B2	Hydraulic Pump—Gear Type.....	61
ELECTRICAL SYSTEM		
11B1	Electrical System.....	62
11C	Rear Lamp, Flasher and Wiring— Wide Fenders and Wiring.....	63
11C3	Rear Lights and Wiring.....	64
11C4	Trailer Socket.....	65
11D2	Battery and Battery Support.....	66
11F2	Starting Motor (4½" Diameter).....	67
11F3	Starting Motor (5" Diameter).....	68
11G1	Generator Assembly.....	69
INSTRUMENT PANEL		
12A1	Instrument Cluster Assembly.....	70


INDEX


Figure No.	Description	Page
TRACTOR SEAT		
13A2	Standard Seat—Basildon	71
13B1	Deluxe Seat.....	72
SHEET METAL AND TOOL BOX		
14A3	Fenders, Platform and Tool Box.....	73
14B2	Engine Hood and Grille.....	74
14C1	Reflector Assembly.....	75
MISCELLANEOUS		
17C1	Cylinder Assembly.....	76
17D1	Tool Kit.....	77

1B1













3A6











4A3







4C3







5B3







5D4






5D7







5F1





5G1





5G2







5H3







6B3







6D2







6F2













7D5








7E3


















7P2







9A3







9F2











11B1







SUPER MAJOR 5000


11C3






11D2







11F3




11G1





12A1









13B1








14B2






17C1







TRACTOR
A PRODUCT OF  MOTOR COMPANY
EQUIPMENT

FORD TRACTOR DIVISION

FORD MOTOR COMPANY